

TS-22-RS/短柄選擇開關



作動模式



Selector Head
2positions 0-I or I-II
switching angle 90°
do.but illuminated version

ON-OFF
ON-ON
2 段選擇



ON-OFF-ON
3 段選擇

Selector Head
3positions I-0-II or 0-I-II
switching angle 45° + 45°
do.but illuminated version

作動模式





作動模式



Selector Head(spring reset)
switching position on the left.
with spring reset to 0-position
from the right.I-0-II
switching angle 45° + 45°
do.but illuminated version


ON-OFF-ON
3 段單邊彈回



ON-OFF
ON-ON
2 段單邊彈回

Selector Head(spring reset)
with spring reset to 0-position
(on the left).0-I
switching angle 90°
do.but illuminated version

作動模式



作動模式



Selector Head(spring reset)
with spring reset to the middle
position I→0←II
switching angle 45° + 45°
do.but illuminated version

ON-OFF-ON
3 段雙邊彈回

